

Air Volume: 10 to 80 CFM

Weight: Approx 12 lbs



In stationary applications where it is important to capture and keep air-borne fumes down low at the work surface level, the Table Sentry may be an excellent selection. By utilizing the optional adjustable-height stand, source capture for elevated operations such as solder pots can be provided as well.

With standard choices of hepa and/or carbon filters, the Table Sentry offers an effective, quiet & economical solution for many bench top operations.

Features

Lightweight & Compact Size
Sturdy Steel Cabinet
HEPA or Other Filters
Durable Construction

Options

Hour Counter
Variable Speed Controller
Variety of Mounting Options
Various Filter Options



Technical Specifications

Overall Dimensions	Work Area Dimensions	Cabinet Material	Electrical	Sound Level
9" D 8" W 11" H	12" D 12" W 6" H	16 ga Carbon Steel w/ Polyester Epoxy Coating on Surface	115/1/60 Approx. .3 amps	58 dba @ 3'

Limited one year warranty from date of shipment on defects due to materials or workmanship.
All specifications are nominal and subject to change without notice.
Not intended for explosive or highly combustible applications.