



PORTABLE ROOM AIR CLEANER SS-450-PRAC

Air Volume:
 950 CFM - Ashrae
 900 CFM - HEPA
 630 CFM - 22lbs Carbon
Weight: 50lbs to 100lbs



Shown with optional features

The patented fan/filter assembly provides strong suction at the extractor inlet providing source capture for many applications. The modular design and sturdy construction make it a solid solution for almost any industrial environment applications. All SAS Units combine small size, quiet operation, convenient mobility, and high efficiency filtration to provide an excellent choice for areas where clean air is desired.



Technical Specifications

Cabinet Dimensions	HEPA Filter	Cabinet Material	Electrical	Sound Level
20" D 20" W 14" H	Up to 99.97% at .3 Microns	16 ga Carbon Steel w/ Polyester Epoxy Coating on Surface	115/1/60 Approx. 10.6 amps	65 dba @ 3'

*Limited one year warranty from date of shipment on defects due to materials or workmanship.
 All specifications are nominal and subject to change without notice.
 Not intended for explosive or highly combustible applications.*

<p>Features</p> <ul style="list-style-type: none"> Lightweight & Compact Size HEPA or Activated Carbon Variable Speed Controller Durable Construction Heavy-Duty Casters
<p>Options</p> <ul style="list-style-type: none"> Hour Counter Magnehelic Gauge Variety of Mounting Options Various Filter Options

USA: 800.799.4609
 INTL: 713.690.2153
 FAX: 713.690.7872

800.799.4609
WWW.SENTRYAIR.COM

Sentry Air Systems, Inc.
 6999 West Little York RD., #P1
 Houston, TX 77040