

Stainless Steel Floor Sentry

Model # SS-100-FS-ST

ESD-SAFE

Product Specifications

BASE UNIT DIMENSIONS

8" Length
8" Width
8.25" Height

ARM DIMENSIONS

3" Round x 43" Long (6" Wide Hood),
Anti-Static Material

CABINET MATERIAL

16 ga. Stainless Steel

WEIGHT

Approx. 8 lbs.

AIR VOLUME

Up to 80 CFM. *Varies with filter media.*

ELECTRICAL

115/1/60, Approx. 0.3 Amps
220/1/50, Approx. 0.2 amps
8' grounded power cord
with NEMA 5-15P Plug

SOUND LEVEL

62 DBA at 3'

FILTRATION

HEPA FILTRATION-
99.97% efficient on particles 0.3 microns and larger.

ASHRAE FILTRATION-
95% efficient on particles 0.5 microns and larger.

These filters are composed of flame-retardant materials.

WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.

PATENT #5,843,197



Dimensions are Approximate

Product Features

- ESD-Safe Base Unit & Anti-Static Flex Hose
- Quiet Operation
- Sturdy Construction
- Highly Portable and Lightweight
- Simple, Quick "No Tool" Filter Change
- Attractive Appearance
- Reliable, Low Maintenance Operation
- Long Filter Life
- Optional Velometer

The **Stainless Steel Floor Sentry** is an ESD-Safe fume extractor that was engineered to free up much needed benchtop workspace. This unit is equipped with a self-supportive, anti-static flex hose that can be easily maneuvered by the operator while the base of the unit either sits on the floor or on the benchtop. The self-supportive hose allows the operator to comfortably adjust the hose to the optimal source-capture position.

This system is equipped with an energy-efficient fan and high-quality filtration media: typically HEPA or ASHRAE filtration. These filters are unique in that the primary materials have been constructed from fire-retardant products. HEPA filtration is up to 99.97% efficient on particles 0.3 microns and larger, while ASHRAE filtration is up to 95% efficient on particles 0.5 microns and larger.

The Stainless Steel Floor Sentry is an effective, quiet & economical solution for many soldering operations which require fume extraction. All of Sentry Air's products are proudly manufactured in the United States and are backed by our two-year limited warranty on parts and labor.



1.800.799.4609
www.sentryair.com
sales@sentryair.com

