

Model 450 Mounted Sentry Fume Extractor



Model # SS-450-MS

The **Model 450 Mounted Sentry Fume Extractor** is an industrial air cleaner that is designed to be mounted directly to or on top of a workbench, a fume hood, or enclosed machinery. This fume extractor is equipped with a powerful fan and a variety of inlet collar sizes (6" and 10" diameter) to match your unique application. This unit's small footprint, lightweight frame, and multiple mounting configurations make it a modular solution for integration with existing machinery. This system also features a variable speed controller and optional remote control.

The **Mounted Sentry Fume Extractor** is typically used for applications including: *laser fume control, chemical fume extraction, pharmaceutical powders, particulate control, printing fumes, soldering, solvent and epoxy fume control, fume/vapor source capture*, and a variety of other applications that *produce smoke, dust, or particulate*.

The **Model 450 Mounted Sentry** has several filter options, including **HEPA filtration** [up to 99.97% efficiency on particles 0.3 microns and larger], **ASHRAE filtration** [up to 95% efficiency on particles 0.5 microns and larger], **ULPA filtration** [up to 99.9995% efficiency on particles 0.12 microns and larger], **Activated Carbon**, and **specialty-blended filtration media** [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]. Filter combinations are customized depending on the application being performed by the operator and multiple filter media can be housed inside the filter chamber for applications that emit both particulates and fumes. Three smaller models [SS-200-MS, SS-300-MS, & SS-400-MS] are also available.



Product Features

- Variable speed controller (115V only)
- On/Off toggle switch (220V only)
- Mounting brackets
- Quiet, reliable, and low maintenance operation
- Low power consumption
- Long filter life
- Simple, quick "no tool" filter change
- **Optional:** magnehelic gauge, hour counter



21221 FM 529 Rd, Cypress, TX 77433
1.800.799.4609 • sales@sentryair.com

www.sentryair.com

Product Specifications



Dimensions are approximate
Shown with optional accessories



21221 FM 529 Rd
Cypress, TX 77433
1.800.799.4609
sales@sentryair.com

www.sentryair.com

Base Unit Dimensions	Length: 22.5" (w/ control box) Width: 22" (w/ brackets) Height: 19.75" (w/inlet)
Inlet Configurations	6" or 10" diameter
Cabinet Material	16 Ga. carbon steel
Weight (approximately)	62 - 112 lbs.
Air Volume (approximately)	High – 950 CFM Low – 50 CFM
Electrical	115/1/60, 10.7 amps 220/1/50, 5.35 amps 8' grounded power cord with NEMA 5-15P plug
Sound Level (at 3' from inlet)	Approx. 72 dba (High)
Main Filter Options	Depending on the Application: HEPA [up to 99.97% efficiency on particles 0.3 microns and larger] ASHRAE [up to 95% efficiency on particles 0.5 microns and larger] ULPA [up to 99.9995% efficiency on particles 0.12 microns and larger] Activated Carbon Specialty-Blended Filter Media [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]
Limited Warranty (From Date of Shipment)	Limited two year warranty on defects due to materials or workmanship. Limited six month warranty on fan/motor assembly
Patent #	5,843,197